

## Care instructions

### Product / Material

**Folding curtain** If the folding curtain no longer glides easily after some time, clean the upper profile thoroughly to remove dust and dirt. Then apply some WD-40 (penetrating oil) to a cloth (not directly to the profile) and rub it into the upper profile. This will restore the sliding properties of the folding door front.

**Metal** The care and cleaning of metal and painted surfaces is unproblematic. Like window panes, they can be cleaned with water and a neutral cleaning agent. Wipe off dust with a dry microfibre cloth without applying pressure and dry with a clean cloth after cleaning with water. Important: Do not use alkaline or acidic cleaning agents. Abrasive or scratching agents such as steel wool and sponges with a scratchy surface must not be used. For stubborn stains, dissolve neutral detergent (pH-neutral) in water according to the manufacturer's instructions. Soak a soft cloth in the cleaning solution and wring out well.

**Linoleum** Loose dirt can be removed using dust-binding cloths or vacuuming. To remove stubborn dirt, dissolve a neutral cleaning agent (neutral pH value) in water according to the manufacturer's instructions. Soak a soft cloth in the cleaning solution and wring out well. Wipe the linoleum surface clean.

*Special instructions:*

- Particularly in the post-oxidation phase, a 'yellow tinge' develops on linoleum. This is particularly noticeable with light colours, but disappears completely when exposed to UV light and the linoleum retains its original colour. On the other hand, this 'yellow tinge' reappears if the flooring surface is covered for a longer period of time, e.g. with monitors, mouse pads etc., but disappears in the same way as described above as soon as the flooring is exposed to daylight again. The 'yellow tinge' cannot be removed by cleaning.
- Flower pots and tubs made of terracotta or clay can leave discolouration on linoleum. Please use suitable coasters.
- Hand and appliance disinfectants can cause stains due to their high solvent content.
- Colouring foods (e.g. ketchup, red wine, coffee, etc.) can leave stains after prolonged exposure, which may not be able to be removed. Please clean the surface immediately if it becomes soiled.
- The desktop material can only withstand heat up to 50°. Rule of thumb: If the object to be placed on the surface can be

**Wood** *Lacquered or oiled furniture*  
It is sufficient to wipe off dust regularly with a soft, dry or slightly damp cloth in the direction of the wood fibres. You can also add a little washing-up liquid to the water. Bleaching and acidic additives are prohibited, as are all other cleaning, polishing or even scouring agents. Acidic liquids, such as fruit juices or alcohol, should be removed immediately.

*Natural wood furniture (untreated wood)*  
Untreated furniture should be cleaned with a dry, possibly damp, but never wet cloth. Please clean lightly soiled areas with furniture soap and a woollen cloth. Please do not use a grease-dissolving household cleaner or steam cleaner. As untreated wood is more susceptible to permanent stains, liquids should be dabbed off immediately and the surface wiped with a damp cloth